TOOLS

External Bending Spring
Kink-free hand bends in multilayer pipe.

Slides over multilayer pipe and supports the outside wall while you bend it by hand, so tight bends do not kink. Fewer elbows needed on UFH and plumbing runs.

CODES

MH-SPRING-16 to MH-SPRING-32



01 · KEY FEATURES

Why installers use it

- **No kinks.** The spring holds the pipe round through the bend.
- **Fewer fittings.** Bend instead of using an elbow where there's room.
- **Pocket-sized.** A light tool to keep in the van.

IN THE BOX

1 bending spring

02 · SPECIFICATION

Technical data

Sizes	16, 20, 25 and 32mm
Fits	Outside of multilayer pipe
Supplied as	One spring

03 · DESIGN HELP

Send us your plans

For design help, send your plans to **sales@maxheatufh.com** or plan loops with **MaxHeatUFH ProLoop** at maxheatufh.com.

04 · SIZES AND CODES

Pick the size, one code each.

4 options by pipe size. Order by code.

PIPE SIZE	CODE
16mm	MH-SPRING-16
20mm	MH-SPRING-20
25mm	MH-SPRING-25
32mm	MH-SPRING-32

05 · WORKS WITH

Complete the system



MLCP Manual Pipe Bender for repeat bends



Pipe Support Bend



PERT-AL-PERT Multilayer Pipe

06 · FITTING AT A GLANCE

Full steps in the install manual

1. Pick the spring that matches the pipe outside size.
2. Mark the centre of the bend on the pipe.
3. Slide the spring over the pipe until it covers the mark.
4. Bend the pipe slowly by hand, spreading the bend along the spring. Over-bend slightly if needed and ease back.

07 · QUESTIONS

Asked by installers

Which size do I need?
Match the spring to the pipe's outside size: 16, 20, 25 or 32mm.

Is it one spring or a set?
One spring. Pick the size you need.

SCAN ME

Watch how it works and fits

Point your phone camera at the code to watch the video for this product.

DESIGN HELP, TRADE ACCOUNTS AND ORDERS

sales@maxheatufh.com **07539 499069**

WEB
maxheatufh.com

DELIVERY
Order by 12pm for next working day delivery