HEATMISER CONTROLS

Heatmiser Edge Multimode Thermostat 230V

One thermostat, four programming modes.

A 230V programmable thermostat you set up four ways on site: non-programmable, 5/2 day, 7 day or 24 hour. One stock item covers almost any UFH or radiator zone, with a white backlight that switches off when idle.

CODE
HM-EDGE



01 · KEY FEATURES

Why installers use it

- Choose the programming mode on site
- Optimum start learns the room and starts early to hit the set time
- Pairs up to 16 wireless air sensors (averaged) or window/door switches, within 40m
- Floor sensor mode with a wired probe (sold separately)
- **Holiday mode,** hold, PIN key lock and Modbus for building controls

IN THE BOX

- Edge thermostat
- Fixing screws

02 · SPECIFICATION

Technical data

Supply	230V AC
Max switching current	3A
Temperature range	5 to 35°C
Programming	Non-programmable, 5/2, 7 day, 24 hour
Heating levels	4 or 6
Size (L x H x D)	90 × 90 × 15mm
Floor sensor	Mode supported, probe not included
Wireless sensors	Up to 16, within 40m

03 · DESIGN HELP

Send us your plans

For design help, send your plans to **sales@maxheatufh.com** or plan loops with **MaxHeatUFH ProLoop** at maxheatufh.com.

04 · ORDER CODE

HM-EDGE.

One code for this product. Check the specification on page 1 before you order.

05 · WORKS WITH

Complete the system

- Heatmiser UH4 or UH8 Wiring Centre
- Heatmiser Wireless Air Sensor
- Heatmiser Temperature Sensor Probe for floor sensing

06 · FITTING AT A GLANCE

Full steps in the install manual

1. Choose a position away from draughts, direct sun and heat sources.
2. Isolate the supply to the heating controls and prove it dead.
3. Fit a back box and bring in the thermostat cable, plus the floor probe cable if used.
4. Wire to the zone terminals of the wiring centre per the Heatmiser diagram supplied.

07 · BEFORE YOU START

Safety

- Isolate the mains supply and prove it dead before removing a front plate or wiring any connection.
- A qualified electrician must make the final mains connections, to BS 7671.
- For indoor, dry locations only. Keep within the stated voltage and switching ratings.



08 · AT A GLANCE

Heatmiser Edge Multimode Thermostat 230V

SUPPLY

230V AC

MAX SWITCHING CURRENT

3A

SCAN ME

Watch how it works and fits

Point your phone camera at the code to watch the video for this product.

DESIGN HELP, TRADE ACCOUNTS AND ORDERS

sales@maxheatufh.com **07539 499069**

WEB

maxheatufh.com

DELIVERY

Order by 12pm for next working day delivery