HEATMISER CONTROLS

Heatmiser Slimline-E Electric Floor Heating Programmable Thermostat 230V 16A electric UFH control, no app.

A 230V programmable thermostat for electric UFH that switches up to 16A and comes with a 3m remote floor sensor. A straightforward choice when the homeowner wants a reliable wall thermostat with no app.

CODE
HM-SLIMLINE-E



01 · KEY FEATURES

Why installers use it

- 16A switching: the mat or cable connects straight to the thermostat
- **3m floor sensor included,** for floor sensing and limiting
- **Non-programmable,** 5/2 day or 7 day, with 4 heating levels
- **Optimum start,** holiday, hold and key lock

IN THE BOX

- Slimline-E thermostat
- 3m floor sensor
- Fixing screws

02 · SPECIFICATION

Technical data

Supply	230V AC
Max switching current	16A
Temperature range	5 to 35°C
Floor limit	20 to 45°C, default 27°C
Floor sensor	3m, included
Size (L x H x D)	99 × 86 × 15mm
Back box	Fits a standard 35mm deep back box
App control	No
RCD	30mA RCD protection required

03 · DESIGN HELP

Send us your plans

For design help, send your plans to **sales@maxheatufh.com** or plan loops with **MaxHeatUFH ProLoop** at maxheatufh.com.

04 · ORDER CODE

HM-SLIMLINE-E.

One code for this product. Check the specification on page 1 before you order.

05 · WORKS WITH

Complete the system

- Electric underfloor heating mats
- MaxHeatUFH Loose Heating Cable
- Heatmiser neoStat-e (the app-controlled alternative)

06 · FITTING AT A GLANCE

Full steps in the install manual

1. Isolate the circuit and prove it dead. The final connection is for a qualified electrician, on a circuit with 30mA RCD protection, to BS 7671.
2. Sink a standard 35mm deep back box and bring in the supply, the mat or cable cold tails, and the floor sensor cable.
3. Lay the floor sensor in a conduit between two heating cable runs, never crossing or touching them, so it can be replaced later.
4. Wire the supply, load and sensor per the Heatmiser diagram supplied (load up to 16A).

07 · BEFORE YOU START

Safety

- ! Isolate the mains supply and prove it dead before removing a front plate or wiring any connection.
- ! A qualified electrician must make the final mains connections, to BS 7671.
- ! For indoor, dry locations only. Keep within the stated voltage and switching ratings.



08 · AT A GLANCE

Heatmiser Slimline-E Electric Floor Heating Programmable Thermostat 230V

SUPPLY

230V AC

MAX SWITCHING CURRENT

16A

SCAN ME

Watch how it works and fits

Point your phone camera at the code to watch the video for this product.

DESIGN HELP, TRADE ACCOUNTS AND ORDERS

sales@maxheatufh.com **07539 499069**

WEB

maxheatufh.com

DELIVERY

Order by 12pm for next working day delivery