HEATMISER CONTROLS

Heatmiser Temperature Sensor Probe

Wired remote sensor, air or floor.

A wired remote sensor for Heatmiser thermostats that accept one. It measures air or floor temperature and is designed to be used as a floor sensor under UFH, where it lets the thermostat control or limit the floor.

CODE

HM-SENSOR-PROBE



01 · KEY FEATURES

Why installers use it

- Floor sensing: control or limit floor temperature
- Air sensing away from the thermostat
- Replace a damaged probe or add floor sensing to a thermostat
- Fit it in a conduit so it can be pulled out and replaced

IN THE BOX

1 sensor probe

02 · SPECIFICATION

Technical data

Type	Wired remote temperature sensor
Use	Air or floor sensing
Works with	Heatmiser thermostats with a remote sensor input: Edge, Touch, neoStat V3, neoStat WiFi
Supplied as	1 probe

03 · DESIGN HELP

Send us your plans

For design help, send your plans to **sales@maxheatufh.com** or plan loops with **MaxHeatUFH ProLoop** at maxheatufh.com.

04 · ORDER CODE

HM-SENSOR-PROBE.

One code for this product. Check the specification on page 1 before you order.

05 · WORKS WITH

Complete the system

- Heatmiser Edge
- Heatmiser neoStat V3
- Pipe Conduit
- Heatmiser Sensor Probe Housing for wall mounting

06 · FITTING AT A GLANCE

Full steps in the install manual

1. Isolate the thermostat circuit before wiring.
2. For floor sensing: lay the probe inside a conduit, between the heating cables or pipes and never on top of them, so it reads the floor and not the heat source. Seal the conduit end.
3. For air sensing: mount the probe (in its housing if wanted) where it reads true room air.
4. Wire the probe to the thermostat sensor terminals per the thermostat manual.

07 · BEFORE YOU START

Safety

- Isolate the thermostat and its circuit before wiring the sensor.
- A qualified electrician must make the final connections where the circuit is mains powered, to BS 7671.
- Route sensor cable away from mains cables to keep readings steady.



08 · AT A GLANCE

Heatmiser Temperature Sensor Probe

TYPE

Wired remote temperature sensor

USE

Air or floor sensing

SCAN ME

Watch how it works and fits

Point your phone camera at the code to watch the video for this product.

DESIGN HELP, TRADE ACCOUNTS AND ORDERS

sales@maxheatufh.com **07539 499069**

WEB
maxheatufh.com

DELIVERY
Order by 12pm for next working day delivery