HEATMISER CONTROLS

Heatmiser UH8 8 Zone Wiring Centre 230V

The standard whole-house UFH wiring centre.

A 230V wiring centre for up to 8 UFH zones, the most common choice for whole-house wet systems. Each mains thermostat opens the actuators on its loops, and the UH8 calls the pump and boiler whenever any zone needs heat.

CODE
HM-UH8



01 · KEY FEATURES

Why installers use it

- **8 zones,** enough for most houses from one manifold
- **Up to 6 actuators per zone,** within the 5A board limit
- Volt-free boiler enable (LS/LR) and a 230V pump output
- Zone 8 switchable to a radiator circuit
- **Wall or DIN rail mounting,** with an LED per zone

IN THE BOX

UH8 wiring centre | DIN rail clips

02 · SPECIFICATION

Technical data

Heating zones	8
Thermostats	230V mains (neoStat V3, Edge, Touch, DS1, DS1-L)
Actuators per zone	Up to 6
Total board load	5A resistive
Relay max load	3A resistive

Supply	230V AC, fused at 5A
Board fuse	5A 20mm anti-surge
Size (L x H x D)	384 × 148 × 60mm
Weight	800g
Protection	IP20

03 · DESIGN HELP

Send us your plans

For design help, send your plans to **sales@maxheatufh.com** or plan loops with **MaxHeatUFH ProLoop** at maxheatufh.com.

04 · ORDER CODE

HM-UH8.

One code for this product. Check the specification on page 1 before you order.

05 · WORKS WITH

Complete the system

- 2-Wire Thermal Actuators 230V
- Heatmiser neoStat V3 thermostats
- Heatmiser neoHub G3 for app control
- Dualmix Stainless Steel Manifold

06 · FITTING AT A GLANCE

Full steps in the install manual

1. Mount the UH8 near the manifold: four screws to the wall, or DIN rail with the two clips supplied.
2. Isolate the supply and prove it dead.
3. Bring in a 230V supply fused at 5A.
4. Wire each room thermostat to its zone input, per the Heatmiser diagram supplied.

07 · BEFORE YOU START

Safety

- Isolate the mains supply and prove it dead before removing a front plate or wiring any connection.
- A qualified electrician must make the final mains connections, to BS 7671.
- For indoor, dry locations only. Keep within the stated voltage and switching ratings.



08 · AT A GLANCE

Heatmiser UH8 8 Zone Wiring Centre 230V

HEATING ZONES

8

THERMOSTATS

230V mains (neoStat V3, Edge, Touch, DS1, DS1-L)

SCAN ME

Watch how it works and fits

Point your phone camera at the code to watch the video for this product.

DESIGN HELP, TRADE ACCOUNTS AND ORDERS

sales@maxheatufh.com **07539 499069**

WEB

maxheatufh.com

DELIVERY

Order by 12pm for next working day delivery