HEATMISER CONTROLS

Heatmiser Wireless Air Sensor
Room sensing with no cable.

Measures room temperature away from the thermostat, with no cable to run. Use it where the thermostat sits in the wrong spot, or group several in a large room so the thermostat works from the average.

CODE

HM-WIRELESS-AIR-SENSOR

PRODUCT



01 · IN THE BOX

What you get

- Wireless air sensor

02 · YOU WILL NEED

Tools and materials

- None for a shelf position; drill and wall plugs for wall mounting

03 · SAFETY

Before you start

- Keep small parts and batteries away from children.
- Indoor, dry locations only.
- No mains wiring: the sensor is battery powered.

04 · INSTALLATION

Fit it in 4 steps.

1. Choose the position that reads true room air: away from draughts, direct sun and heat sources, within range of the thermostat or hub.
2. Pair the sensor to the thermostat (Edge or Touch), or to the neoHub for use with a neoStat.
3. For an averaged reading, pair the group of sensors and the thermostat will use the average.
4. Fix the sensor in place.

05 · TESTING AND COMMISSIONING

Test, check, then hand over

- [x] Check the thermostat shows the sensor reading and it tracks the room.

06 · CARE AND MAINTENANCE

Keep it working

- Replace the battery when the thermostat flags it.

07 · WORKS WITH

Parts that fit with it

Heatmiser Edge | Heatmiser Touch | Heatmiser neoHub G3

08 · MANUFACTURER DOCUMENTS

Official Heatmiser documents

Heatmiser wireless sensors (official)
https://www.heatmiser.com/wireless-sensors/

09 · JOB RECORD

Fill in on site, keep for the handover

Site / room

Installed by

Date

Test result

Notes

SCAN ME

Watch how it works and fits

Point your phone camera at the code to watch the video.

QUESTIONS ON SITE?

sales@maxheatufh.com **07539 499069**

WEB
maxheatufh.com

DELIVERY
Order by 12pm for next working day delivery