Manifold Flow Meter

See and balance each loop

Code: MHM-FM



In the box

- 1 flow meter

You will need

- Spanner

Safety

- Installation should be carried out by a competent installer, in line with the system design and BS EN 1264.
- Isolate and drain down, or isolate with the manifold ball valves, before working on a filled system.
- Hot water and pressure can cause injury. Let the system cool and release pressure before opening any joint.

Installation

1. Check it matches the meters already on the manifold (send us a photo if unsure).
2. Isolate the manifold and release the pressure.
3. Unscrew the old meter and fit the new one.
4. Refill, vent and check the reading.
5. Set the loop to its design flow rate.

Testing and commissioning

- ✓ Check the meter reads with the loop open and drops to zero when closed.

Care and maintenance

- A cloudy or stuck meter can be swapped the same way.