Edge Insulation Foam Roll 100mm x 5mm

Perimeter expansion strip for screeds

Code: MH-EDGE-25M, MH-EDGE-50M



In the box

- 1 roll of edge strip

You will need

- Tape measure
- Sharp knife
- Staple gun or clips to hold it in place

Safety

- Installation should be carried out by a competent installer, in line with the system design and BS EN 1264.
- Wear gloves and eye protection when cutting pipe, handling metal plates or using hand tools.
- Release system pressure and let pipework cool before cutting into or disturbing any filled pipe.

Installation

1. Measure the perimeter of each room plus around any columns.
2. Fit the strip tight to the walls and round columns before the floor insulation goes down.
3. Lay the floor insulation up to the strip; this helps hold it in place.
4. Where large and small areas meet, and at doorways where pipes pass through, form an expansion joint from a length of strip with holes cut for the pipes.
5. Lay the pipe and screed.
6. Once the screed is down, trim the excess strip flush with the floor finish.

Testing and commissioning

- ✓ Check the strip is continuous around the room with no gaps before screeding.