
MaxHeatUFH Castellated Floor Panel 1220 x 820mm

20mm clip-free panel for 15 to 17mm pipe

Code: MaxHeatCrate-20



In the box

- Castellated floor panels, 1220 x 820mm

You will need

- Knife
- Pipe decoiler
- Pressure test pump

Safety

- Installation should be carried out by a competent installer, in line with the system design and BS EN 1264.
- Wear a dust mask and eye protection when cutting boards, and gloves when handling adhesives, primers and compounds.
- Follow the instructions and safety data sheets for every primer, adhesive and levelling compound used with the system.

Installation

1. Prepare the subfloor as the screed or compound maker requires, with any insulation the floor design calls for.
2. Fit edge insulation foam around the room perimeter.
3. Lay the panels across the whole floor, cutting them to fit at the walls.
4. Push the pipe in between the bosses, following the loop design.
5. Connect each loop to the manifold and pressure test.
6. Pour the screed or self-levelling compound over the panel.

Testing and commissioning

- ✓ Pressure test all loops before pouring, to BS EN 1264, and keep them under pressure while the floor is poured.

Care and maintenance

- Follow the screed or compound maker's drying and first heat-up times.