Uncoupling / Decoupling Membrane for Electric Underfloor Heating (1m Wide Roll)

Tile protection over electric heating

Code: MH-DCM-1x5 to MH-DCM-1x15



In the box

- 1 roll of membrane

You will need

- Tape measure
- Sharp knife
- Notched trowel
- Flexible tile adhesive

Safety

- Take care with the knife, especially near heating cable that is already laid.
- Use flexible tile adhesive throughout and follow the adhesive maker's instructions.
- Protect any heating cable from tools and foot traffic until it is tiled over.

Installation

1. Measure the floor area to be tiled and pick a roll that covers it, with a little extra for cuts.
2. Check the subfloor is solid and clean. Prime it if your adhesive needs it.
3. Cut the membrane to length with a sharp knife.
4. Spread flexible tile adhesive and bed the fleece side into it, pressing it down for full contact.
5. Lay the electric heating as its own instructions say. Loose cable presses between the membrane studs.
6. Tile on top with flexible tile adhesive.

Testing and commissioning

- ✓ Check the membrane is flat and fully bedded before laying the heating.