COPPER M-PRESS FITTINGS

Copper M-Press Female Tee
Pressed run, female threaded branch.

Press ends on the run and a female threaded branch, for adding a drain cock, air vent, pressure gauge, sensor pocket or threaded valve to a copper run.

CODES

MHF9-T15x1/2Fx15-BAG10 to MHF9-T54x1/2Fx54-BOX10



01 · KEY FEATURES

Why installers use it

- **Threaded branch.** Screw in a gauge, vent or drain without an extra adaptor.
- **Eight sizes.** 15mm to 54mm runs.
- **Pressed run.** Flame-free on both run ends with M-profile jaws.
- **Full packs.** Bag or box. 42mm and 54mm are box only.

IN THE BOX

Fittings in a full bag or box (quantity is in the code, e.g. BAG10 = 10)

02 · SPECIFICATION

Technical data

Sizes	Read run, branch, run: 22mm x 1/2" x 22mm
Branch	Female thread
Press profile	M-profile
Pipe	Copper tube
Jaws (MaxHeatUFH)	15, 22, 28mm: MH-EHCS or MH-HPEHCS. 35, 42, 54mm: MH-HPEHCS only
Packs	Full bags or boxes, not split

03 · GOOD TO KNOW

Reading the size

Sizes read run end, threaded branch, run end. So 22mm x 1/2" x 22mm has 22mm press ends and a 1/2" female branch.

04 · DESIGN HELP

Send us your plans

For design help, send your plans to **sales@maxheatufh.com** or plan loops with **MaxHeatUFH ProLoop** at maxheatufh.com.

05 · SIZES AND CODES

Pick the size, one code each.

14 options by size, pack. Order by code.

SIZE	BAG CODE	BOX CODE
15mm x 1/2" x 15mm	MHF9-T15x1/2Fx15-BAG10	MHF9-T15x1/2Fx15-BOX80
22mm x 1/2" x 22mm	MHF9-T22x1/2Fx22-BAG5	MHF9-T22x1/2Fx22-BOX50
22mm x 3/4" x 22mm	MHF9-T22x3/4Fx22-BAG5	MHF9-T22x3/4Fx22-BOX40
28mm x 1/2" x 28mm	MHF9-T28x1/2Fx28-BAG5	MHF9-T28x1/2Fx28-BOX35
28mm x 3/4" x 28mm	MHF9-T28x3/4Fx28-BAG5	MHF9-T28x3/4Fx28-BOX30
35mm x 1/2" x 35mm	MHF9-T35x1/2Fx35-BAG5	MHF9-T35x1/2Fx35-BOX20
42mm x 1/2" x 42mm		MHF9-T42x1/2Fx42-BOX15
54mm x 1/2" x 54mm		MHF9-T54x1/2Fx54-BOX10

06 · PACK SIZES

SIZE	BAG	BOX
15mm x 1/2" x 15mm	10	80
22mm x 1/2" x 22mm	5	50
22mm x 3/4" x 22mm	5	40
28mm x 1/2" x 28mm	5	35
28mm x 3/4" x 28mm	5	30
35mm x 1/2" x 35mm	5	20
42mm x 1/2" x 42mm	-	15
54mm x 1/2" x 54mm	-	10

07 · WORKS WITH

Complete the system



Copper M-Press Equal Tee



Copper M-Press Unequal Tee



Copper M-Press Male Straight

08 · FITTING AT A GLANCE

Full steps in the install manual

1. Cut the tube square with a tube cutter.
2. Deburr the tube end inside and out and wipe it clean.
3. Mark the insertion depth on the tube.
4. Check the seal is seated in the socket and undamaged.

SCAN ME

Watch how it works and fits

Point your phone camera at the code to watch the video for this product.

DESIGN HELP, TRADE ACCOUNTS AND ORDERS

sales@maxheatufh.com **07539 499069**

WEB

maxheatufh.com

DELIVERY

Order by 12pm for next working day delivery