Eurocone Connector Cores 3/4"

Pipe connectors for 3/4" Eurocone outlets

Code: MHF1-C0710x3/4A to MHF1-C1620x3/4A



In the box

- 1 connector core: nut, split olive, pipe insert

You will need

- Pipe cutter
- Reaming tool
- Spanners

Safety

- Installation should be carried out by a competent installer, in line with the system design and BS EN 1264.
- Isolate and drain down, or isolate with the manifold ball valves, before working on a filled system.
- Hot water and pressure can cause injury. Let the system cool and release pressure before opening any joint.

Installation

1. Check the size printed on the pipe (for example 16 x 2.0) and pick the core with the same figures.
2. Cut the pipe square with a pipe cutter and ream the end so the insert slides in cleanly.
3. Slide the nut, then the split olive, onto the pipe.
4. Push the insert fully into the pipe end.
5. Offer the pipe to the Eurocone outlet, push it home and tighten the nut by hand.
6. Finish with a spanner. Do not overtighten; hold the outlet steady so the manifold bar does not twist.

Testing and commissioning

✓ Check every core for weeps during the pressure test, and again once the system is up to temperature.

Care and maintenance

- If a joint weeps, isolate, release pressure and re-make it with a new core.