TOOLS

External Bending Spring
Kink-free hand bends in multilayer pipe.

Slides over multilayer pipe and supports the outside wall while you bend it by hand, so tight bends do not kink. Fewer elbows needed on UFH and plumbing runs.

CODES

MH-SPRING-16 to MH-SPRING-32

PRODUCT



01 · IN THE BOX

What you get

- 1 bending spring

02 · YOU WILL NEED

Tools and materials

- Marker pen

03 · SAFETY

Before you start

- Read these instructions before first use and keep the tool clean and in good condition.
- Wear suitable gloves and eye protection.
- Keep hands clear of blades, jaws and moving parts, and never use a damaged tool.

04 · INSTALLATION

Fit it in 5 steps.

1. Pick the spring that matches the pipe outside size.
2. Mark the centre of the bend on the pipe.
3. Slide the spring over the pipe until it covers the mark.
4. **Bend the pipe slowly by hand, spreading the bend along the spring.** Over-bend slightly if needed and ease back.
5. Slide the spring off.

05 · TESTING AND COMMISSIONING

Test, check, then hand over

- [x] Check the bend is round with no flattening or kinks.

06 · CARE AND MAINTENANCE

Keep it working

- Keep the spring clean and free of grit.

07 · QUESTIONS

Asked by installers

Which size do I need?

Match the spring to the pipe's outside size: 16, 20, 25 or 32mm.

Is it one spring or a set?

One spring. Pick the size you need.

08 · WORKS WITH

Parts that fit with it



MLCP Manual Pipe Bender for repeat bends



Pipe Support Bend



PERT-AL-PERT Multilayer Pipe

09 · JOB RECORD

Fill in on site, keep for the handover

Site / room

Installed by

Date

Test result

Notes

SCAN ME

Watch how it works and fits

Point your phone camera at the code to watch the video.

QUESTIONS ON SITE?

sales@maxheatufh.com **07539 499069**

WEB
maxheatufh.com

DELIVERY
Order by 12pm for next working day delivery