HEATMISER CONTROLS

Heatmiser neoStat 12V App Controlled Programmable Thermostat

Low-voltage neoStat for 12V systems.

The low-voltage version of the neoStat smart thermostat. It runs on 12V DC from a 12V network wiring centre such as the Heatmiser UH8-N, keeping mains voltage out of the thermostat back boxes. Add a neoHub for app control of every zone.

CODES

HM-NEOSTAT-12V-W, -B, -S

PRODUCT



01 · IN THE BOX

What you get

- neoStat 12V thermostat
- Fixing screws

02 · YOU WILL NEED

Tools and materials

- Small screwdrivers
- 35mm deep wall back box
- Voltage tester

03 · SAFETY

Before you start

- Isolate the mains supply and prove it dead before removing a front plate or wiring any connection.
- A qualified electrician must make the final mains connections, to BS 7671.
- For indoor, dry locations only. Keep within the stated voltage and switching ratings.

04 · INSTALLATION

Fit it in 7 steps.

1. Plan the runs back to the UH8-N: the thermostats wire to the 12V and network terminals of the wiring centre.
2. Isolate the 230V supply to the wiring centre and prove it dead.
3. Sink a standard 35mm deep back box per zone and pull in the cable.
4. Wire each neoStat to its zone terminals per the Heatmiser diagram supplied with the UH8-N.
5. Fit the thermostat to the back box and restore power at the wiring centre.
6. Choose thermostat or timer mode and the sensing mode.
7. To add app control, pair it to the neoHub from the neoApp.

05 · TESTING AND COMMISSIONING

Test, check, then hand over

- [x] Raise the set temperature and check the matching zone responds at the UH8-N.
- [x] Check every zone number matches its room before handover.

06 · CARE AND MAINTENANCE

Keep it working

- Wipe with a dry cloth only.

07 · WORKS WITH

Parts that fit with it

- Heatmiser UH8-N 12V Network Wiring Centre
- Heatmiser neoHub G3 for app control
- Heatmiser Temperature Sensor Probe for floor sensing

08 · MANUFACTURER DOCUMENTS

Official Heatmiser documents

Heatmiser neoStat 12V datasheet (official)
https://www.heatmiser.com/download/329/neo-datasheets/14858/neostat-12v-v3-1-datasheet.pdf

09 · JOB RECORD

Fill in on site, keep for the handover

Site / room

Installed by

Date

Test result

Notes

SCAN ME

Watch how it works and fits

Point your phone camera at the code to watch the video.

QUESTIONS ON SITE?

sales@maxheatufh.com **07539 499069**

WEB
maxheatufh.com

DELIVERY
Order by 12pm for next working day delivery