HEATMISER CONTROLS

Heatmiser Sensor Probe Housing

Tidy wall mount for the sensor probe.

A small cover for mounting a Heatmiser remote sensor probe on the wall. It gives a tidy finish when the probe senses air temperature away from the thermostat. The probe is sold separately.

CODE
HM-SENSOR-HOUSING



01 · KEY FEATURES

Why installers use it

- Hides the probe in a plain housing
- Made by Heatmiser for its own sensor probe
- A low-cost add-on when ordering the probe

IN THE BOX

1 probe housing

02 · SPECIFICATION

Technical data

Fits	Heatmiser Temperature Sensor Probe
Use	Wall mounting for air sensing
Probe	Not included

03 · DESIGN HELP

Send us your plans

For design help, send your plans to **sales@maxheatufh.com** or plan loops with **MaxHeatUFH ProLoop** at maxheatufh.com.

04 · ORDER CODE

HM-SENSOR-HOUSING.

One code for this product. Check the specification on page 1 before you order.

05 · WORKS WITH

Complete the system

- Heatmiser Temperature Sensor Probe
- Heatmiser Thimble Sensor

06 · FITTING AT A GLANCE

Full steps in the install manual

1. Choose a wall position that reads true room air.
2. Fix the housing to the wall.
3. Seat the sensor probe in the housing and route its cable back to the thermostat.

07 · BEFORE YOU START

Safety

- No mains wiring: the housing holds a low-voltage sensor probe.
- Indoor, dry locations only.
- Keep small parts away from children.



08 · AT A GLANCE

Heatmiser Sensor Probe Housing

FITS

Heatmiser Temperature Sensor Probe

USE

Wall mounting for air sensing

SCAN ME

Watch how it works and fits

Point your phone camera at the code to watch the video for this product.

DESIGN HELP, TRADE ACCOUNTS AND ORDERS

sales@maxheatufh.com **07539 499069**

WEB
maxheatufh.com

DELIVERY
Order by 12pm for next working day delivery