HEATMISER CONTROLS

Heatmiser Sensor Probe Housing

Tidy wall mount for the sensor probe.

A small cover for mounting a Heatmiser remote sensor probe on the wall. It gives a tidy finish when the probe senses air temperature away from the thermostat. The probe is sold separately.

CODE

HM-SENSOR-HOUSING

PRODUCT



01 · IN THE BOX

What you get

- 1 probe housing

02 · YOU WILL NEED

Tools and materials

- Small screwdriver
- Drill and wall plugs

03 · SAFETY

Before you start

- No mains wiring: the housing holds a low-voltage sensor probe.
- Indoor, dry locations only.
- Keep small parts away from children.

04 · INSTALLATION

Fit it in 3 steps.

1. Choose a wall position that reads true room air.
2. Fix the housing to the wall.
3. Seat the sensor probe in the housing and route its cable back to the thermostat.

05 · TESTING AND COMMISSIONING

Test, check, then hand over

- [x] Check the thermostat reading tracks the room.

06 · CARE AND MAINTENANCE

Keep it working

07 · WORKS WITH

Parts that fit with it

Heatmiser Temperature Sensor Probe

Heatmiser Thimble Sensor



08 · AT A GLANCE

Heatmiser Sensor Probe Housing

FITS

Heatmiser Temperature Sensor Probe

USE

Wall mounting for air sensing

09 · JOB RECORD

Fill in on site, keep for the handover

Site / room

Installed by

Date

Test result

Notes

SCAN ME

Watch how it works and fits

Point your phone camera at the code to watch the video.

QUESTIONS ON SITE?

sales@maxheatufh.com **07539 499069**

WEB

maxheatufh.com

DELIVERY

Order by 12pm for next working day delivery