HEATMISER CONTROLS

Heatmiser Slimline-RF Wireless Digital Programmable Thermostat

Wireless, buttons not apps.

A battery-powered wireless programmable thermostat for homeowners who want buttons rather than an app. It pairs with the UH8-RF wiring centre or the RF-Switch receiver, so no thermostat cable is needed.

CODE
HM-SLIMLINE-RF



01 · KEY FEATURES

Why installers use it

- **868MHz radio,** no thermostat cable
- 4 heating levels and 4 hot water times
- **Wireless fail-safe built in,** plus optimum start, holiday, hold and key lock
- **Wall mount,** with an optional desk stand
- **Remote air sensor supported,** up to 20m away

IN THE BOX

- Slimline-RF thermostat
- Fixing screws

02 · SPECIFICATION

Technical data

Power	2 x AAA batteries (typically a year, per Heatmiser)
Radio	868MHz
Range	Up to 100m (page); Heatmiser datasheet states 40m in open space
Temperature range	5 to 35°C
Accuracy	±1°C
Programming	Non-programmable, 5/2, 7 day
Size (L x H x D)	85 × 98 × 24mm
App control	No

03 · DESIGN HELP

Send us your plans

For design help, send your plans to **sales@maxheatufh.com** or plan loops with **MaxHeatUFH ProLoop** at maxheatufh.com.

04 · ORDER CODE

HM-SLIMLINE-RF.

One code for this product. Check the specification on page 1 before you order.

05 · WORKS WITH

Complete the system

- Heatmiser UH8-RF Wireless Wiring Centre
- Heatmiser RF-Switch Two Channel Receiver

06 · FITTING AT A GLANCE

Full steps in the install manual

1. Fit the receiver first: a UH8-RF at the manifold, or an RF-Switch at the boiler (mains work for a qualified electrician).
2. Fit the batteries and choose the wall position, away from draughts, direct sun and heat sources.
3. Pair the thermostat to its receiver zone, following the Heatmiser pairing steps supplied.
4. Set the programme: heating levels, and hot water times if used.

07 · BEFORE YOU START

Safety

- The receiver or wiring centre it pairs with is mains powered: isolate that supply before wiring.
- A qualified electrician must make the final mains connections at the receiver or wiring centre, to BS 7671.
- Use the battery size stated and do not mix old and new batteries.



08 · AT A GLANCE

Heatmiser Slimline-RF Wireless Digital Programmable Thermostat

POWER

2 x AAA batteries (typically a year, per Heatmiser)

RADIO

868MHz

SCAN ME

Watch how it works and fits

Point your phone camera at the code to watch the video for this product.

DESIGN HELP, TRADE ACCOUNTS AND ORDERS

sales@maxheatufh.com **07539 499069**

WEB

maxheatufh.com

DELIVERY

Order by 12pm for next working day delivery