Manifold Flow Meter

See and balance each loop

Code: MHM-FM



> Sits on the flow bar and shows how much water is going round each loop, so you can balance the system and see when a loop is not flowing.

Key features

- See each loop's flow
- Balance so all rooms heat evenly
- Replace one meter, not the whole manifold

Specification

Fits	UFH manifold flow bar
Supplied as	1 flow meter

Works with

- Auto-Balancing Stainless Steel UFH Manifold
- Manifold Auto Air Vent End Unit

Specifications may change. For design help, send your plans to sales@maxheatufh.com or try MaxHeatUFH ProLoop at maxheatufh.com.