TOOLS

Multilayer (MLCP) Pipe Straightener 16 to 20mm

Roller straightener for coiled pipe.

Takes the coil set out of multilayer pipe (MLCP or PERT-AL-PERT). Pull the pipe through the rollers and it comes out straight, for neat manifold tails, surface runs and radiator connections.

CODE

MH-STRAIGHTENER-1620

PRODUCT



01 · IN THE BOX

What you get

- 1 pipe straightener

02 · YOU WILL NEED

Tools and materials

- Pipe cutter

03 · SAFETY

Before you start

- Read these instructions before first use and keep the tool clean and in good condition.
- Wear suitable gloves and eye protection.
- Keep hands clear of blades, jaws and moving parts, and never use a damaged tool.

04 · INSTALLATION

Fit it in 4 steps.

1. Set the straightener for the pipe size, 16mm or 20mm.
2. Feed the end of the pipe from the coil into the rollers.
3. Pull the pipe steadily through in one direction.
4. Cut the straightened length off and use it as needed.

05 · TESTING AND COMMISSIONING

Test, check, then hand over

- [x] Check the pipe surface for marks after the first pass.

06 · CARE AND MAINTENANCE

Keep it working

- Keep the rollers clean and free of grit.

07 · QUESTIONS

Asked by installers

Which pipe sizes does it take?

16mm and 20mm multilayer pipe.

Where is it most useful?

On manifold connections and exposed pipe runs, where straight pipe looks neater.

08 · WORKS WITH

Parts that fit with it



MLCP Manual Pipe Bender



PERT-AL-PERT Multilayer Pipe

ALSO WORKS WITH

UFH Manifolds

09 · JOB RECORD

Fill in on site, keep for the handover

Site / room

Installed by

Date

Test result

Notes

SCAN ME

Watch how it works and fits

Point your phone camera at the code to watch the video.

QUESTIONS ON SITE?

sales@maxheatufh.com **07539 499069**

WEB

maxheatufh.com

DELIVERY

Order by 12pm for next working day delivery