TOOLS

Pipe Reaming Tool

Re-rounds and deburrs the pipe bore.

A star reamer that prepares multilayer and plastic pipe after cutting. Push and twist it into the pipe end to re- round the bore and deburr the inside edge, so fittings seat without damaging the O-rings.

CODES

MH-REAMER-12-16-20, MH-REAMER-16-20-25



01 · KEY FEATURES

Why installers use it

- **Protects the O-rings.** A smooth, round bore stops the seals being nicked.
- **Two versions.** 12/16/20mm or 16/20/25mm heads.
- **For MLCP, PERT-EVOH and PEX.** Works on all common UFH pipe.
- **Light.** Fits in a tool pouch.

IN THE BOX

1 reaming tool

02 · SPECIFICATION

Technical data

Versions	12/16/20mm or 16/20/25mm heads
Pipe	MLCP, PERT-EVOH, PEX

03 · DESIGN HELP

Send us your plans

For design help, send your plans to **sales@maxheatufh.com** or plan loops with **MaxHeatUFH ProLoop** at maxheatufh.com.

04 · SIZES AND CODES

Pick the size, one code each.

2 options by sizes. Order by code.

SIZES	CODE
12/16/20mm	MH-REAMER-12-16-20
16/20/25mm	MH-REAMER-16-20-25

05 · WORKS WITH

Complete the system



Pipe Cutter 14-32mm



Pipe Chamfering Tool

ALSO WORKS WITH

MLCP Fittings

06 · FITTING AT A GLANCE

Full steps in the install manual

1. Cut the pipe square first.
2. Pick the head that matches the pipe size.
3. Push the head into the pipe end and twist it a few turns until the bore is round and the inside edge is smooth.
4. Tap out any shavings from the pipe.

07 · QUESTIONS

Asked by installers

Which version should I pick?

12/16/20mm if you use 12mm pipe, 16/20/25mm if you work with 25mm pipe.

When do I use it?

After every cut, before pushing the pipe into the fitting.



08 · AT A GLANCE

Pipe Reaming Tool

VERSIONS

12/16/20mm or 16/20/25mm heads

PIPE

MLCP, PERT-EVOH, PEX

SCAN ME

Watch how it works and fits

Point your phone camera at the code to watch the video for this product.

DESIGN HELP, TRADE ACCOUNTS AND ORDERS

sales@maxheatufh.com **07539 499069**

WEB

maxheatufh.com

DELIVERY

Order by 12pm for next working day delivery