
PUMPS & CONTROLS

Single Room UFH Mixing Pump Pack with Bastion A-Rated 7.5m Pump

One room, longer loop, 35 to 60°C.

A pre-assembled single room mixing pump pack with the higher-head Bastion A-rated 7.5m pump, for a larger room or a longer single loop. It heats one room straight off a radiator or boiler circuit, with no manifold.

CODE
MH-SR-BAS75



01 · KEY FEATURES

Why installers use it

- **7.5m head.** For larger rooms and longer loops.
- **35 to 60°C mixed flow.** Set by the thermostatic valve.
- **Primary isolation valves.** Fitted, so the pack can be isolated for service.
- **Pre-wired terminal box.** A quicker electrical connection on site.

IN THE BOX

- Pre-assembled pack on its bracket
- Pump power cable
- Allen key for the valve cap

02 · SPECIFICATION

Technical data

Mixing valve	Thermostatic, 35 to 60°C
Factory setting	43°C
Circuits	1 (single room)
Fitted	Primary isolation valves, pre-wired terminal box
Max system pressure	10 bar
Mounting	Wall bracket with anti-vibration mounts
Electrical	230V, from a 3A fused spur
Pump	Bastion A-rated, 7.5m head, cable included
Mixed flow temperature	35 to 60°C

03 · ORDER CODE

MH-SR-BAS75.

One code for this product. Check the specification on page 1 before you order.

04 · WORKS WITH

Complete the system



PERT-AL-PERT Multilayer UFH Pipe



Bastion Replacement Pump Cables



Pressure / Temperature Gauge for UFH Mixing Unit

ALSO WORKS WITH

Heatmiser DS1 Thermostat

05 · FITTING AT A GLANCE

Full steps in the install manual

1. Choose a wall with room for the pipework and for servicing. Mount it level with the terminal box at the top, or upright. Never on the floor or with the pump shaft vertical.
2. Mark the fixing holes through the bracket, drill and plug the wall, and screw the pack in place.
3. Connect the UFH loop to the pack. If the floor is going to be screeded first, fill and pressurise the loop through the isolation valves and lock them off.
4. Connect the primary flow and return from the radiator or boiler circuit to the isolation valves. Make sure air can be vented to protect the pump.

06 · QUESTIONS

Asked by installers

Should I pick 6m or 7.5m?

The 6m pack covers most single rooms. Pick this 7.5m pack for a long loop or bigger room. Send us your plans if you want us to check.

What rooms is it for?

Any room with a single UFH circuit, such as an extension, kitchen or conservatory.

07 · DESIGN HELP

Send us your plans

For design help, send your plans to **sales@maxheatufh.com** or plan loops with **MaxHeatUFH ProLoop** at maxheatufh.com.

SCAN ME

Watch how it works and fits

Point your phone camera at the code to watch the video for this product.

DESIGN HELP, TRADE ACCOUNTS AND ORDERS

sales@maxheatufh.com

07539 499069

WEB
maxheatufh.com

DELIVERY
Order by 12pm for next working day delivery